Commercial Electric™

Item # 716-262
Model #ML-2W-5'-12EA

Use and Care Guide

Rope Light Accessory Kit

TOOLS REQUIRED



Phillips screwdriver

HARDWARE INCLUDED

A - Mounting Clip x12

B - Mounting screw x12

Installation

1 Installing the mounting clips

- ☐ Insert the screws (B) through the openings in the mounting clips (A).
- ☐ Screw the mounting clips (A) into position at the installation location. Ensure that each mounting clip (A) is evenly spaced apart and at least 1 cm apart from the other mounting clips (A).
- ☐ Place sections of the rope light (1) securely into the mounting clips (A).



Safety Information

WARNING: Do not mount or secure the rope light in a manner that can cut the outer jacket or damage the cord insulation. Inspect the rope light carefully before use and discard any rope lights that have a broken outer jacket, loose connections, or frayed wire insulation.

WARNING: When using this product outdoors, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

WARNING: Do not cover rope lighting as the covering may cause the flexible light to overheat and either melt or ignite.

WARNING: Do not puncture, cut, shorten, or splice the flexible lighting.

WARNING: Do not use if there is any damage to the light or cord insulation. Inspect periodically.

WARNING: Do not submerge the flexible light in liquids or use the product in the vicinity of standing water or other liquids.

WARNING: Secure the rope lights using only the mounting clips provided. Do no secure this product with staples, nails, or similar objects that may damage the insulation.

CAUTION: All units must be unplugged before you add additional segments. Only use segments recommended by the manufacturer of this lighting system.

CAUTION: Ensure all connections and the end cap on the last segment are tightly secured to prevent the entry of water.

Warranty

The manufacturer warrants this product to be free for two (2) years against any defects that are due to faulty materials or workmanship. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation or any other failure not relating to faulty workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specifically disclaims any warranty, whether expressed or implied, or fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including any labor/expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-877-527-0313 or visit www.HomeDepot.com.